

Wet/Dry Shaver													
Triple Blade													
	ES8249	ES8243	ES8109	ES8101	ES8168	ES8163	ES8162	ES8161	ES8807	ES8078	ES8044	ES8043	ES8813
	WES9161Y				WES9087Y				WES9065Y				WES9085Y
	WES9068Y				WES9066Y				WES9064Y				
	WES9020Y			WES9013Y			WES9011Y			WES9012Y			
Detergent Cartridge	WES035	—	WES035	—	WES035	—			WES035	—			

Wet/Dry Shaver													
Triple Blade									Double Blade				
	ES7109	ES7102	ES7101	ES7058	ES7038	ES7036	ES6003	ES6002		ES4033	ES4025		
	WES9085Y									Outer Foil	WES9837Y		
	WES9064Y									Inner Blade	WES9850Y		
	WES9012Y									Foil and Blade Set	WES9839Y		
Detergent Cartridge	WES035	—		WES035	—			Detergent Cartridge	—				

Wet/Dry Shaver	Travel Shaver		Ladies Shaver		Facial Trimmer		Manicure Care	Pedicure Care		
Single Blade										
	ES3042	ES4815	ES3830	ES2235	ES2211	ES2113P	ES2113A	ES2401	ES2502	
	WES9941Y	WES9837Y	WES9941Y	WES9775Y		Downy Hair Blade	WES9275PY	WES9275AY	WES0171Y	WES0191Y
	WES9942Y	WES9850Y	WES9942Y	WES9752Y			WES9257PY	WES9257AY		
Foil and Blade Set	WES9839Y		—		Eyebrow Blade		—			

Hair Clipper					Beard/Hair Trimmer				
									
ER5209	ER508	ER510	ER2403	ER240	ER230	ER221	ER220	ER217	ER206
WER9103Y	WER9102Y	WER9601Y	WES9606Y	WER961Y	ER965	WER9602Y		WER9601Y	

Professional Hair Clipper							
							
ES291	ER160	ER154	ER149	ER148	ER145	ER145	ER121
WES9273Y		WER9792Y		WER9712Y	WER9711Y	WER9181Y	WER935Y

Shaver		Model No.	Accessory	
Wet/Dry Shaver	Triple Blade	ES8093,ES8092	Outer Foil	WES9063Y
			Inner Blade	WES9064Y
		ES8080	Outer Foil	WES9061Y
			Inner Blade	WES9074Y
		ES8068,ES8066,ES7006,ES7003,ES883,ES882,ES766,ES765,ES762	Outer Foil	WES9075Y
			Inner Blade	WES9074Y
	ES8026,ES8018,ES8017,ES7027,ES7026,ES7017,ES7016	Outer Foil	WES9077Y	
		Inner Blade	WES9074Y	
	Double Blade	ES8003	Foil and Blade Set	WES9007Y
			Outer Foil	WES9081Y
			Inner Blade	WES9080Y
	Double Blade	ES4032,ES4027,ES4001,ES805,ES723	Outer Foil	WES9837Y
			Inner Blade	WES9850Y
			Foil and Blade Set	WES9839Y
		ES744,ES743,ES742,ES705,ES704,ES703,ES702	Outer Foil	—
Inner Blade			WES9870Y	
ES727,ES726,ES725,ES722,ES719,ES718			Outer Foil	WES9835Y
	Inner Blade	WES9850Y		
Single Blade	ES3041,ES3001,ES876,ES843,ES815,ES366,ES365	Outer Foil	WES9941Y	
		Inner Blade	WES9942Y	
Dry Shaver		ES375,ES372	Outer Foil	WES9973Y
			Inner Blade	—
Card-Sized Shaver		ES518,ES514	Outer Foil	WES9933Y
			Inner Blade	WES9932Y
Ladies Shaver		ES209,ES207	Outer Foil	WES9775Y
			Inner Blade	WES9752Y
		ES206,ES204,ES201,ES179,ES177,ES173	Outer Foil	WES9753Y
			Inner Blade	WES9752Y
Manicure System		ES103	File Set	ES017

Trimmer	Model No.	Accessory	
Hair Clipper	ER508W	WER9102Y	
	ER507	WER936Y	
Beard/Hair Trimmer	ER216,ER215	Trimmer Blade	WER966Y
		Outer Foil	WES9786Y
		Inner Blade	WES9787Y
	ER214,ER213	WER966Y	
	ER211,ER210	WER963Y	
	ER205,ER204,ER203	WER964Y	
Professional Hair Clipper	ES290	ES9264	
	ER721,ER130	WER9130Y	
	ER153,ER152	WER9792Y	
	ER147	WER9712Y	
	ER146	WER9711Y	
	ER141	WER9130Y	
	ER140	ER9199	