

# Panasonic

- Recommendation of Men's Shaver replacement parts:
- Empfehlung zum Austausch der Scherteile bei Herrenrasierern:
- Pièces de remplacement recommandées pour les rasoirs hommes:
- Consigli sulla sostituzione dei pezzi del Rasoio elettrico per Uomo:
- Recomendación sobre partes de reemplazo para la rasuradora masculina:



Replace outer foil once every year  
 Austausch der Scherfolie einmal pro Jahr  
 Remplacer la grille externe une fois par an  
 Sostituire la retina esterna una volta all'anno  
 Reemplaza la hoja externa una vez al año



Replace inner blade once every two years  
 Austausch der Schermesser alle zwei Jahre  
 Remplacer la lame interne une fois tous les deux ans  
 Sostituire la lama interna una volta ogni due anni  
 Reemplaza la cuchilla interna una vez cada dos años



Foil and Blade set  
 Schermesser und Scherfolien Set  
 Jeu de grille et de lame  
 Set Lama e retina  
 Juego de hoja y cuchilla

## WET/DRY MEN'S SHAVER



ES-LV81 ES-LV61 ES-LA93 ES-LA63 ES8249 ES8243 ES-LT71 ES8109 ES8103 ES8101 ES-GA21 ES8807

OUTER FOIL	WES9171Y	WES9165Y	WES9161Y	WES9087Y	WES9065Y
INNER BLADE	WES9170Y	WES9068Y			WES9068Y
FOIL AND BLADE SET	WES9030Y	WES9025Y	WES9020Y	WES9013Y	WES9011Y
DETERGENT CARTRIDGE	WES035	WES035	WES035	WES035	

## WET/DRY MEN'S SHAVER



ES-LF71 ES-LF51 ES-RF41 ES-RF31 ES8813 ES8043 ES-RT81 ES-RT51 ES-RT31 ES7109 ES7102 ES7101 ES7036 ES-RL21

OUTER FOIL	WES9167Y	WES9085Y
INNER BLADE	WES9068Y	WES9064Y
FOIL AND BLADE SET	WES9027Y	WES9012Y
DETERGENT CARTRIDGE	WES035	WES035

## WET/DRY MEN'S SHAVER

## BODY SHAVER



ES-RW30 ES-SA40 ES4815 ES3830 ER-GY50 ER-GY30 ES2265 ES2263

OUTER FOIL	WES9835Y (ES9835)	WES9941Y	WES9837Y	WES9941Y	ES9775
INNER BLADE	WES9850Y	WES9942Y	WES9850Y	WES9942Y	WES9752Y(ES9752)
FOIL AND BLADE SET			WES9839Y		

## BEARD/HAIR TRIMMER

## HAIR CLIPPER



ER-GY10 ER2403 ER2302 ER2211 ER2201 ER2171 ER2061 ER-GC70 ER-GC50 ER-GC20 ER-CA70 ER-CA35 ER5209

INNER BLADE	WER9606Y	ER965	WER9602Y	WER9601Y	WER9605Y
-------------	----------	-------	----------	----------	----------

Shavers	Model No.	Accessory No.	
Wet/Dry Men's Shaver	ES8168, ES8163, ES8162	Outer Foil	WES9065Y
		Inner Blade	WES9068Y
		Foil and Blade Set	WES9011Y
		Detergent Cartridge (ES8168)	WES035
	ES8093, ES8092	Outer Foil	WES9063Y
		Inner Blade	WES9064Y
	ES8080	Outer Foil	WES9061Y
		Inner Blade	WES9074Y
	ES8068, ES8066, ES7006, ES7003, ES883, ES882, ES766, ES765, ES762	Outer Foil	WES9075Y
		Inner Blade	WES9074Y
	ES8078, ES8044, ES7058, ES7038 ES6003, ES6002	Outer Foil	WES9085Y
		Inner Blade	WES9064Y
		Foil and Blade Set	WES9012Y
		Detergent Cartridge (ES8078, ES7058)	WES035
ES8026, ES8018, ES8017, ES7027, ES7026, ES7017, ES7016	Outer Foil	WES9077Y	
	Inner Blade	WES9074Y	
	Foil and Blade Set	WES9007Y	
ES8003	Outer Foil	WES9081Y(ES9081)	
	Inner Blade	WES9080Y(ES9080)	
ES4033, ES4032, ES4029, ES4027, ES4025, ES4001, ES805, ES723	Outer Foil	WES9837Y	
	Inner Blade	WES9850Y	
	Foil and Blade Set	WES9839Y	
ES744, ES743, ES742, ES705, ES704, ES703, ES702	Inner Blade	WES9870Y(ES9870)	
	ES727, ES726, ES725, ES722, ES719, ES718	Outer Foil	WES9835Y(ES9835)
Inner Blade		WES9850Y	
ES3042, ES3041, ES3001, ES876, ES843, ES815, ES366, ES365	Outer Foil	WES9941Y	
	Inner Blade	WES9942Y	
Dry Shaver	ES375, ES372	Outer Foil	WES9973Y(ES9973)
Card-Sized Shaver	ES518, ES514	Outer Foil	WES9933Y(ES9933)
		Inner Blade	WES9932Y(ES9932)
Beauty Care	Model No.	Accessory No.	
Epilator	ES-WD92, ES-WD42 ES-WD92, ES-WD72, ES-WD70, ES-WD52, ES-WS20, ES2067, ES2058, ES2057, ES2055, ES2047, ES2028, ES2027	Foot Care File	WES2W31Y
		Outer Foil	WES9753Y(ES9753)
		Inner Blade	WES9752Y(ES9752)
Ladies Shaver	ES2291, ES2235, ES2211, ES209, ES207	Outer Foil	ES9775
		Inner Blade	WES9752Y(ES9752)
	ES206, ES204, ES201, ES179, ES177, ES173	Outer Foil	WES9753Y(ES9753)
		Inner Blade	WES9752Y(ES9752)
Facial Trimmer	ES2113P	Downy Hair Blade	WES9275PY
		Eyebrow Blade	WES9257PY
	ES2113A	Downy Hair Blade	WES9275AY
		Eyebrow Blade	WES9257AY
Manicure Care	ES2401	File Set	WES0171Y
	ES103	File Set	ES017
Pedicure Care	ES2502	File and Polish Set	WES0191Y
Trimmers	Model No.	Accessory No.	
Hair Clipper	ER510		WER9601Y
	ER508		WER9102Y
	ER507		WER936Y
Beard/Hair Trimmer	ER240		WER961Y (ER961)
	ER2301, ER230		ER965
	ER221, ER220, ER217		WER9602Y
	ER216, ER215	Trimmer Blade	WER966Y
		Outer Foil	WES9786Y
		Inner Blade	WES9787Y
	ER214, ER213		WER966Y
	ER211, ER210		WER963Y(ER963)
ER206		WER9601Y	
ER205, ER204, ER203		WER964Y (ER964)	